



AmpliDECT400BT

**Digital Cordless Telephone
with Large Buttons and
Blue Tooth**



English

CONTENTS

CONTENTS	1
INTRODUCTION	4
Unpacking the Telephone	5
DESCRIPTION	6
General Description	6
INSTALLATION	14
Menu Navigation	14
Location	15
Setting Up	16
Battery Use	18
Using the Belt Clip	18
Wall Mounting	19
On/Off Settings	20
HANDSET SETTINGS	21
Alarm	21
Ringer Tones	22
Ringer Volume	23
Key Tone Settings	25
Language	26
Handset Name	27
LCD Contrast	28
Auto Answer	29
Amplification	30
Date Format	31
Date & Time	33
Range Alarm	34
Selecting a Base	35
BASE SETTINGS	37
Release a Handset	37
Dial Mode	38

CONTENTS

Flash Settings	39
PIN Settings	40
BLUETOOTH	42
Pairing with a Bluetooth Headset	42
Connecting the Headset	43
Disconnecting the Headset	44
Removing a Paired Headset	46
USING THE TELEPHONE	48
Making a Call	48
Call Switching	49
Receiving a Call	49
Mute Function & Handsfree	50
Receiving Volume	52
Last Number Redial	53
Recalling Recent Numbers	53
Deleting Recent Numbers	54
Adding Recent Numbers to Phonebook	55
Paging the Handset, Call Timer, Key Lock	56
CALLER DISPLAY	58
View Caller Display List	59
Dial a Number from the Caller Display List	60
Delete an Entry from the Caller Display List	61
Delete all Entries from the Caller Display List	62
Add Entry from the Caller Display List to Phone Book	63
PHONE BOOK	65
Character Map	65
Create a Phone Book Entry	66
View Phone Book Entries	68
Dialing using the Phone Book	68
Modify a Phone Book Entry	69

CONTENTS

Delete a Phone Book Entry	70
Delete all Phone Book Entries	71
Phone Book Status	72
ONE TOUCH MEMORIES	73
Storing Memory Numbers	73
Viewing Memory Numbers	73
Dialling a Memory Number	74
Editing a Memory Number	74
Deleting a Memory Number	75
ADDITIONAL HANDSETS & BASES	77
Register a New Handset	78
Select a Base	79
Internal Calls	80
Call Transfer between Handsets	81
Three Way Conference Call	83
CALL WAITING	84
Caller Display on Call Waiting	84
DEFAULT SETTINGS	85
Handset reset	85
ACCESSORIES	86
Optional Accessories	86
TROUBLESHOOTING	87
SAFETY INFORMATION	89
GUARANTEE	90
RECYCLING DIRECTIVES	92

INTRODUCTION

Congratulations on purchasing your Geemarc AmpliDECT400BT telephone. This telephone offers all the advantages of cordless technology (compliant with Digitally Enhanced Cordless Telecommunications-DECT standard) together with large buttons which are helpful if you are partially sighted. This telephone is also hearing aid compatible. The AMPLI DECT400BT has Bluetooth, enabling you to connect to a compatible headset effortlessly and without the bother of trailing wires.

It is important that you read the instructions below in order to use your Geemarc telephone to its full potential. Keep this user guide in a safe place for future reference.

This guide explains how to use the following telephone:

AmpliDECT400BT

This guide applies to single and multiple handset systems.

INTRODUCTION

Unpacking the Telephone

When unpacking the telephone, you should find the following in the box:

- 1 AmpliDECT400BT handset
- 1 AmpliDECT400BT base
- 1 Mains power adaptor
- 1 Telephone line cord
- 1 Belt clip
- 3 x AAA rechargeable batteries
- 1 User Guide



For product support and help visit our website at

www.geemarc.com


Telephone 01707 384438

Or fax 01707 372529


DESCRIPTION

General Description


Handset Description



DESCRIPTION




DESCRIPTION




DESCRIPTION

Base Description



Rear of Base Description



(*) Classified "hazardous voltage" according to EN60950 standard

(**) Classified TNV-3 according to EN60950 standard

DESCRIPTION






LCD Screen Description

The LCD screen is split into two distinct areas:




The icon area. This is found at the top of the screen. This displays the various system icons which help you to use the telephone.

The main area. This is found across the centre of the screen. It displays the following:





- number being dialled
- call display information
- phonebook
- menu information
- in standby mode, handset number and current time

	New Call This indicates you have missed one or more calls
	Signal Strength icon This shows the current signal strength. More bars indicate more signal strength. If the handset is too far from the base, the icon will blink
	Line icon This indicates that the line is engaged
	Key Lock icon This indicates the keypad is locked
	MSG Waiting icon This indicates that you have one or more voice messages

DESCRIPTION

	Handsfree icon This indicates handsfree loudspeaker is activated.
	Alarm icon This appears when you set an alarm to ring at a specified time.
	Battery Status icon This is always displayed when your telephone is switched on. It shows the level of battery charge. More bars indicate more battery charge

Keys Description

	Landline Key Make/Answer calls
	Bluetooth Key Make/Answer calls through a Bluetooth Headset
	Speaker Key Activates the speakerphone if pressed during a call
	End Key End a call Long press to power the telephone on/off

DESCRIPTION



Navigation Key



UP/CID key

Scroll up through lists and menu options

Increase the earpiece/
speakerphone volume during a call

Enter the Call List



Down/Phonebook Key

Scroll down through lists and menu options

Decrease the earpiece/
speakerphone volume during a call

Enter the Phonebook



Int Key

Set up an internal call to another handset

Transfer an incoming call to another handset

Set up a conference call with an external line and an internal handset









Redial Key

Enter the Redial List

Insert a pause when pre-dialing a number



DESCRIPTION

	Left/Right Soft Key Performs the function shown by the text immediately above it on screen. This text is context sensitive.
	One touch Memory Keys Store up to 4 numbers for one-touch memory dialing
	* Key Press and hold to turn on/off keypad lock
	# Key Press and hold to turn on/off torch
	0 Key Press and hold this key until the icon appears to activate the shaker and visual ringer function. Press and hold this key again until the  icon disappears to deactivate it.

INSTALLATION

Menu Navigation

Press '**MENU**' soft key to activate the menu

To scroll through the menu options, press  or 

To select a menu, press the '**SELECT**' soft key when the desired menu option is displayed on the screen.

Press the '**BACK**' soft key to return to the previous screen.

Press  to return to standby mode.

INSTALLATION


Location

Ensure you situate the telephone close enough to the power socket so that the cable will reach safely without stretching. Also, the mains power needs to be easily accessible in case you need to disconnect the power.

Make sure the telephone is at least 1 metre away from other electrical products e.g. TV, radio and monitors so as to avoid interference. Also, avoid direct heat and sunlight.

We advise you to place the telephone on a table cloth or similar, as the rubber feet on the base can mark some surfaces

Handset Range


The telephone has a range of 30-50 metres indoors and up to 300 metres outdoors. The range will be reduced when there is no clear line of sight between the base and handset. Place the base as high as practically possible to ensure the best signal between the base and the handset. The  icon at the top left of the LCD display will flash and the signal strength bars will disappear to warn you if you have moved out of range of the base. You will need to move closer to the base station as the telephone line might be disconnected and the handset will return to standby.

INSTALLATION

Setting Up

Plug the power cable into the power socket on the base. Plug the adaptor into the mains supply and switch the supply on. (*)


Connect the line cord plug to the line socket on the base. Connect the other end of the line cord to the PTT socket. (**)



To AC wall outlet To phone wall outlet

Install the rechargeable batteries into the handset. The handset requires three Nickel Metal Hydride (NiMH) AAA batteries. These are supplied with your telephone.

- 1) Slide the battery cover in the direction of the arrow.
- 2) Insert batteries as indicated, ensuring to match polarity (+, -).



INSTALLATION

3) To replace the battery cover, slide the cover up until it snaps into place.



Place the handset on the base. The battery icon will be displayed on the handset. Once the handset is fully charged, the display will show a full battery symbol.

The telephone has an automatic charging control to avoid excessive charging.


Before the handset can be used, the handset batteries must be charged for a minimum of 15 hours on the AmpliDECT400BT base.

(*) Classified "hazardous voltage" according to EN60950 standard

(**) Classified TNV-3 according to EN60950 standard.

INSTALLATION

Battery Use

The  icon is continuously displayed at the top right corner of the LCD display. The icon indicates the level of battery power. The more bars displayed, the more power left.



When the battery is too weak for the telephone to operate, the handset will automatically switch off. Place the handset on the base to charge the handset battery. Under ideal conditions, the handset battery should give about 6 hours talk time or 24 hours standby on a single charge.

Using the Belt Clip

The belt clip supplied allows you to conveniently carry the handset around. It clips easily to your belt, waist band or shirt pocket.


Attach Belt Clip

Attach the belt clip to to the rear of the handset. Make sure the belt clip locks into place.

Remove Belt Clip


Insert a screw driver along the edge of one of the belt clip arms and release the clip. Lift the clip off the handset.

INSTALLATION




Wall Mounting


Place the plate for wall mounting under the telephone. Drill 2 holes in the wall 60 mm apart, insert the wall plugs and the wall mounting screw. The screws should protrude 6-7 mm. Fit the base onto the screw-heads and slide down to secure.



INSTALLATION

On/Off Settings

When the handset is placed on the charger it automatically switches on. Alternatively, press . Once switched on, the handset will enter subscription mode and search for a registered base.



If the handset finds a base, the handset will enter standby mode and is now ready for use.



If the handset is unsuccessful in finding a base, the handset will behave as if Out of Range. Try moving closer to the base.

To turn the handset off, press . The LCD display will then disappear and switch off.

HANDSET SETTINGS



Alarm

Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select
'HS SETTING'

Press **'SELECT'** soft key

Press **'SELECT'** soft key to select
'ALARM'

Use  and  to scroll through the menu to select
'ON' or **'OFF'**

Press **'SELECT'** soft key



If you select ON, you are invited to enter the time in HH:MM format (24 hr format). When alarm sounds, press any key to stop the alarm.

Press **'SELECT'** soft key

HANDSET SETTINGS

'**SNOOZE**' will be displayed. (snooze of 11 minute intervals).

Press '**SELECT**' soft key



Use  and  to scroll through the menu to select
'**ON**' or '**OFF**'

Press '**SELECT**' soft key.



Ringer Tones

There is a choice of 10 handset ringer tones (5 melodic, 5 polyphonic) to notify you of incoming calls.

Press '**MENU**' soft key to activate the menu

Use  and  to scroll through the menu to select
'**HS SETTINGS**'

Press '**SELECT**' soft key

Use  and  to scroll through the menu to


HANDSET SETTINGS

select
'RING SETUP'

Press **'SELECT'** soft key

. Press **'SELECT'** soft key to choose **'INT RING'**

Or

Press  then **'SELECT'** soft key to choose **'EXT RING'** (from the external network)



You can select the ring tone from Melody 1 to 10. When you adjust the ring tone, the phone sounds the selected melody.

Press **'SELECT'** soft key

Ringer Volume

There is a choice of five handset ringer volumes. The handset ringer can also be turned off.



Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select

HANDSET SETTINGS



'HS SETTINGS'

Press **'SELECT'** soft key

Use  and  to scroll through the menu to select

'RING SETUP'

Press **'SELECT'** soft key

Use  and  to scroll through the menu to select

'VOLUME'

Press **'SELECT'** soft key

You can select the ringer volume from Volume 1 to 5, or Volume Off.

Press **'SELECT'** soft key


Notes: If you set the volume to **'OFF'**, when a call comes in, only the **'NEW CALL'** information appears on the LCD.

HANDSET SETTINGS



Key Tone Settings

There are 2 options for the key tone each time a key is pressed, ON or Off

Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select
'HS SETTING'

Press **'SELECT'** soft key



Use  and  to scroll through the menu to select
'TONE SETUP'

Press **'SELECT'** soft key

Press **'SELECT'** soft key to select
'KEY TONE'

Press **OK**

HANDSET SETTINGS



Use  and  to scroll through the menu to select either
'ON' or **'OFF'**

Press **'SELECT'** soft key



Language

The handset supports 7 language, (English, German, French, Italian, Turkish, Spanish and Portuguese). You can choose the language used to display menu messages.

Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select
'HS SETTING'

Press **'SELECT'** soft key

Use  and  to scroll through the menu to select
'LANGUAGE'

HANDSET SETTINGS

Press '**SELECT**' soft key



Use ▲ and ▼ to scroll through the menu to select desired language. Each language will be displayed in its native translation

Press '**SELECT**' soft key to save selection and return to standby. A confirmation beep will be heard

Handset Name



The handset label is displayed in the standby mode. This name can be modified..

Press '**MENU**' soft key to activate the menu

Use  and  to scroll through the menu to select

'HS SETTING'

Press '**SELECT**' soft key

Use  and  to scroll through the menu to select

'HS NAME'

HANDSET SETTINGS

Press '**SELECT**' soft key



Enter the handset name using the alphanumeric keys (up to 12 characters (use the '**ERASE**' to delete the previous character if necessary)

Press '**SAVE**' soft key. Handset name will be displayed above the handset number is standby.



LCD Contrast

The visibility of the display can be optimised using this setting according to the environment.

Press '**MENU**' soft key to activate the menu

Use  and  to scroll through the menu to select
'HS SETTING'



Press '**SELECT**' soft key

Use  and  to scroll through the menu to select

HANDSET SETTINGS

'LCD CONTRAST'

Press **'SELECT'** soft key

Use  and  to scroll through the the 17 available contrast settings (0-16)



'LCD CONTRAST'

Press **'SAVE'** soft key

Auto Answer



When auto answer is on, you can answer a call by simply picking up the handset from the base without pressing a key.

Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select

'HS SETTING'



Press **'SELECT'** soft key

Use  and  to scroll through the menu to

HANDSET SETTINGS

select
'AUTO ANSWER'

Press **'SELECT'** soft key



Use  and  to scroll through the menu to select either
'ON' or **'OFF'**

Press **'SELECT'** soft key to save selection and return to standby, you will hear a confirmation beep

Amplified



When amplification is on, the amplify function will be On every time a call starts. You will not need to press the ad hoc **AMP** button. If you switch this function on, the handset receiver volume adjustment is 15-30 d B. Otherwise the receiver adjustment button is 0-15dB.

Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select
'HS SETTING'



HANDSET SETTINGS

Press **'SELECT'** soft key

Use  and  to scroll through the menu to select

'AMPLIFIED'

Press **'SELECT'** soft key



Use  and  to scroll through the menu to select either

'ON' or **'OFF'**

Press **'SAVE'** soft key to save selection and return to standby

Date Format



Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select

'HS SETTING'



HANDSET SETTINGS

Press **'SELECT'** soft key

Use  and  to scroll through the menu to select



'DATE & TIME'

Press **'SELECT'** soft key

Use  and  to scroll through the menu to select

'DATE FORMAT' or **'TIME FORMAT'**

Press **'SELECT'** soft key

Use  and  to scroll through the menu to select either

'DD-MM' or **'MM-DD'** for date format

Or

'12-HOUR' or **'24-HOUR'** for time format

Press **'SAVE'** soft key

Note: If you select the 12-HOUR time format, AM or PM will appear on the right of the time in standby mode.



HANDSET SETTINGS

Date and Time



Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select
'HS SETTING'

Press **'SELECT'** soft key

Use  and  to scroll through the menu to select
'DATE AND TIME'

Press **'SELECT'** soft key

Use  and  to scroll through the menu to select
'SET DATE' or **'SET TIME'**

Press **'SELECT'** soft key

Use the keypad to enter the correct date or time.
Note: Valid hours are between 00 and 23 (inclusive)

HANDSET SETTINGS

i.e. 24hr format



Press **'SAVE'** soft key

Notes: If you subscribe to a Caller Display service, the time will be set automatically.



Range Alarm

A beep will be heard when the handset is out of range of the base during a call. You can enable/disable this audible warning.

Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select
'HS SETTING'

Press **'SELECT'** soft key



Use  and  to scroll through the menu to select
'TONE SETUP'

Press **'SELECT'** soft key

HANDSET SETTINGS

Press  to select **'RANGE ALARM'**

Press **'SELECT'** soft key



Use  and  to scroll through the menu to select either
'ON' or **'OFF'**

Press **'SELECT'** soft key

Selecting a Base



You can select a base other than the one already registered to the handset

Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select
'HS SETTING'



Press **'SELECT'** soft key

HANDSET SETTINGS

Use  and  to scroll through the menu to select

'SELECTED AS'

Press **'SELECT'** soft key

Use  and  to scroll through the list of registered bases

Press **'SELECT'** soft key once you have found the desired base



'SEARCHING' will be displayed initially then
'BS SELECTED'

BASE SETTINGS

Release a Handset

A registered handset can be removed from a base if necessary

Press **'MENU'** soft key to activate the menu



Use  and  to scroll through the menu to select **'BS SETTING'**

Press **'SELECT'** soft key

Press **'SELECT'** soft key to select **'DELETE HS'**

The display will show **'PIN?'** Use the keypad to type in your PIN (default 0000)

Press **'SELECT'** soft key

All handsets currently registered with the base will be displayed on the LCD display. Use  and  to select the handset to be released

BASE SETTINGS



Press **'SELECT'** soft key. The released handset will now behave as an unregistered handset.

Note: If you select the handset you are using a warning tone will be heard.


Dial Mode

In the UK, all telephone exchanges now use Tone dialling. The dial mode setting is pre-set to Tone. If your telephone does not dial out, it is probably being used from an older private switchboard (PBX). In this case, the dial mode must be changed to Pulse.

Press **'MENU'** soft key to activate the menu



Use  and  to scroll through the menu to select **'BS SETTING'**

Press **'SELECT'** soft key

Press  to select **'DIAL MODE'**

Press **'SELECT'** soft key

BASE SETTINGS



Use  and  to scroll through the menu to select either
'TONE' or **'PULSE'**

Press **'SELECT'** soft key to save selection and return to standby, a confirmation beep will be heard



Flash Time

The Flash time can be changed if required.

Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select
'BS SETTING'



Press **'SELECT'** soft key

Use  and  to scroll through the menu to select
'FLASH TIME'

Press **'SELECT'** soft key

BASE SETTINGS

The current setting is shown on the LCD display.

Use  and  to scroll through the menu to select either



'100ms' (UK) , '300ms' or '600ms'

Press '**SELECT**' soft key

Personal Identification Number (PIN) Settings



The PIN is required for a number of options e.g. registering a new handset and resetting a handset. The PIN is pre-set to '0000'. This can be changed – this is recommended for confidentiality.

Press '**MENU**' soft key to activate the menu

Use  and  to scroll through the menu to select

'**BS SETTING**'

Press '**SELECT**' soft key

Use  and  to scroll through the menu

BASE SETTINGS

to select
'MODIFY PIN'

Press **'SELECT'** soft key

The display shows **'PIN?'** Use the keypad to type in the current PIN (if you enter an incorrect PIN, a warning beep will be heard and the telephone returns to **'MODIFY PIN'** menu)

Press **'SELECT'** soft key

Use the keypad to type in the new PIN. The range is 0000 – 9999

Press **'SELECT'** soft key

Use the keypad to type in the new PIN again for confirmation purposes

Press **'SELECT'** to save the new PIN and return to standby

BLUETOOTH



Pairing with Bluetooth Headset



Ensure you have Bluetooth Headset User Guide ready to consult.

Up to 8 devices can be paired with your Bluetooth handset.

Set Bluetooth Headset to pairing mode (refer to user guide if required)



Press '**MENU**' soft key to activate the menu

Use  and  to scroll through the menu to select '**BLUETOOTH**' and press '**SELECT**' soft key

Use  and  to scroll through to select **ON** to activate the function or **OFF** and press '**SELECT**' soft key



Press '**SELECT**' soft key to select '**ADD DEVICE**'. **Please Wait** will be displayed the Bluetooth LED will flash



BLUETOOTH



The screen displays all the devices found. Use  and  to scroll through to select the correct device and press '**SELECT**' soft key. You will then hear a tone through the headset-the devices are connected.

Connecting the Headset

Press '**MENU**' soft key to activate the menu



Use  and  to scroll through the menu to select '**BLUETOOTH**' and press '**SELECT**' soft key

Use  and  to scroll through to select **ON** to activate the function or **OFF** and press '**SELECT**' soft key

Use  and  to scroll through the menu to select '**DEVICE LIST**'

. Press '**SELECT**' soft key

BLUETOOTH

Use  and  to scroll through the list of devices that have been paired before until you find the desired device

. Press '**SELECT**' soft key

Press '**SELECT**' soft key to select
'CONNECT'



When the connection is successful, the Bluetooth LED on the handset switches on

Note: If you turn the Bluetooth headset off, when you turn it back on again, you may need to connect to the handset again

To get the best quality sound, stay within 3 metres of the base.



Disconnecting the Headset



Press '**MENU**' soft key to activate the menu

Use  and  to scroll through the menu to select



BLUETOOTH

'BLUETOOTH' and press **'SELECT'** soft key

Use  and  to scroll through to select **ON** to activate the function or **OFF** and press **'SELECT'** soft key

Use  and  to scroll through the menu to select
'DEVICE LIST'

. Press **'SELECT'** soft key

Use  and  to scroll through the list of devices that have been paired before until you find the desired device

. Press **'SELECT'** soft key

Press **'SELECT'** soft key to select
'DISCONNECT'

A tone will be heard through the headset



BLUETOOTH

Removing a Paired Headset



Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select
'BLUETOOTH'



Press **'SELECT'** soft key

Use  and  to scroll through the menu to select
'DEVICE LIST'

Press **'SELECT'** soft key

Use  and  to scroll through the list of devices that have been paired before until you find the desired device

. Press **'SELECT'** soft key

Use  and  to scroll through the menu to

BLUETOOTH

select
'REMOVE'

Press **'SELECT'** soft key to delete the paired device

Note: If you turn the Bluetooth headset off, when you turn it back on again, you may need to connect to the handset again

To get the the best quality sound, stay within 3 metres from the base.


USING THE TELEPHONE

Making a Call

Pick up handset.



Press  or 


Dial the number on the keypad

To end the call simply press  or place the handset on the base


Pre-Dialling

Pick up handset. Dial the number on the keypad (up to 24 digits).

Press  or , the number is automatically dialled

To end the call simply press  or place the handset on the base


Note: If you make an incorrect entry while pre - dialling the telephone number:

- Press '**ERASE**' soft key to clear the last digit and then enter the correct number
- Press  to insert a pause if required

USING THE TELEPHONE


Call Switching


You can switch between the handset and the Bluetooth headset during a call (the handset must be paired and connected to the Bluetooth headset).



During a call using the handset, press , the call will switch to the Bluetooth headset.

During a call using the Bluetooth headset, press , the call will switch to the handset.

Receiving a Call

When an incoming call is received the telephone rings and the  icon will flash on the LCD display. If the caller can be identified (due to subscription to a Caller Display service), the caller's telephone number will be displayed.


If the caller cannot be identified, '**NEW CALL**' will be displayed. If you have a voice message, '**MSG WTG ON**' and  icon will be shown on the LCD.

Press  to answer a call through the handset
or , to answer the call through a connected
Bluetooth headset

If auto answer activated, when the handset is in the


USING THE TELEPHONE

base, simply lift it up to answer.

To end the call simply press  or place the handset on the base

Note: You can change the ringer volume by using



and  when the telephone rings with an incoming call.

If the polyphonic ring tone (Melody 6-10) is selected, the ring tone may continue for a few seconds after another handset registered to the base is answered or after a caller has hung-up.

Deactivate Icon

Press  while in standby

Then press and hold '4'

Press  to return to standby

Mute Function

If you wish, you can speak privately to someone else in the room without your caller overhearing. You will still be

USING THE TELEPHONE

able to hear the caller but they cannot hear you during the mute operation.

During a call, press **'MUTE SOFT KEY'**

The LCD display will show **'MUTED'** which indicates that your voice is muted to the call and the caller cannot hear you speaking

Press **'MUTE SOFT KEY'** again to resume the conversation.

Handsfree

During a call, you may turn on the speakerphone built in the handset. Whilst in handsfree mode you simply place your handset on a surface such as a desk or table and enjoy the freedom of handsfree.

During a call, press



The LCD display will show



Press



icon will disappear

USING THE TELEPHONE

Receiving Volume

During a conversation, the **VOL+** or **VOL-** keys adjust the ear piece or handsfree speakerphone volume level. The volume can be adjusted from level 1 to 5. The selected volume is displayed in the LCD display.




You can also use the **AMP** key on the right hand side of the handset. This will give an extra boost to the volume 40dB. When you press this key during a conversation, the red Amplify indicator on the handset lights up. If you press this key again, the extra amplification will stop and the indicator will switch off.

To adjust the tone to suit your hearing requirements, use the **TONE** control on the right hand side of the handset.

Caution: This telephone can produce very loud sound levels. Repeated exposure to amplification levels greater than 18dB may be harmful to people without hearing loss.


USING THE TELEPHONE

Last Number Redial



Recalling Recent Numbers

You can call back any of the last 10 numbers dialled as follows:



Notes:


- When no numbers are found, **EMPTY** is displayed
- If the redial memory is full i.e. 10 numbers stored, each time you dial a new number, the oldest number stored is automatically erased and the redial memory is updated.



USING THE TELEPHONE

Deleting Recent Numbers



To delete a specific number in the redial memory

Pick up handset.

Press  in standby mode

Use  and  to scroll through the dialled numbers until you find the number you wish to delete


Press **'MORE'** soft key

Use Use  and  to scroll through the menu to select **'DELETE'**

Press **'SELECT'** soft key or Press **'BACK'** soft key to cancel



To delete all numbers in the redial memory

Pick up handset.

Press  in standby mode


Press **'MORE'** soft key



USING THE TELEPHONE

Use  and  to scroll through the menu to select
'DELETE ALL'



Press **'SELECT'** soft key or Press **'BACK'** soft key to cancel

Adding Recent Numbers to Phonebook

Pick up handset.
Press  in standby mode

Use  and  to scroll through the dialled numbers until you find the number you wish to add to Phonebook

Press **'MORE'** soft key

Use  and  to scroll through the menu to select
'ADD to PB'

USING THE TELEPHONE


Press '**SELECT**' soft key or Press '**BACK**' soft key to cancel

Complete storing the Phonebook entry as described in Adding Phonebook Entries (Phonebook Chapter). Obviously, the telephone number will already be typed in.


Press '**SELECT**' soft key or Press '**BACK**' soft key to cancel

Paging the Handset

If you wish to locate the handset simply follow the instructions below:

Press , located on the front of the base for less than 5 seconds

All registered handsets will be paged and will ring for about 60 seconds

Press '**BACK**' soft key on the handset to stop paging mode.
Alternatively, press  on the base to stop paging mode

USING THE TELEPHONE

Call Timer

Your handset automatically times the duration of every external call. The time is shown during the call and for a few seconds after the call has ended.

Key Lock

When this feature is turned on, all buttons will be locked and will not function.

Incoming or intercom calls can be answered by using



However, when you complete the call and hang up, the telephone returns to lock mode.

This feature is useful to avoid pressing buttons by mistake.

Switch lock On: Press until icon is displayed.

Switch lock Off: Press until icon disappears from the display.

Note: In locked mode, if you press any key, you will hear a warning tone.

CALLER DISPLAY


The features described in this section are only available if you subscribe to a Caller Display service from your network provider.

Caller Display means you can see who is calling on your handset display (provided the number is not withheld, unavailable or is an international call).

The display shows **'PRIVATE'** for a withheld number.

The display shows **'OUT OF AREA'** when someone calls from an area where Caller display is not offered by the telephone service provider.

Whether you take a call or not, the caller's details are stored in the Call list. The call list stores the last 20 incoming calls.

The  symbol will be shown on the handset display if you receive a call in your absence. When the call list memory is full, this icon will blink on the LCD.



CALLER DISPLAY


View Caller Display List

Press '**MENU**' soft key to activate the menu

Press '**SELECT**' soft key to choose
'CID BOOK'

If available, the telephone numbers will be displayed

Use  and  to scroll through the numbers

Notes: You can also access the CID book directly by pressing  in standby mode.

If there are no caller ID telephone numbers in the call list, **EMPTY** is displayed.

Each telephone number in the CID book is marked with an arrow:



The call has been reviewed



The call has not been reviewed



CALLER DISPLAY

Dial a Number from the Caller Display List

Press '**MENU**' soft key to activate the menu

Press '**SELECT**' soft key to choose
'**CID BOOK**'

If available, the telephone numbers will be displayed

Use  and  to scroll through the numbers to find the required number



Press  or , to dial the number

CALLER DISPLAY



Delete an Entry from the Caller Display List

Press **'MENU'** soft key to activate the menu

Press **'SELECT'** soft key to choose **'CID BOOK'**

Use  and  to scroll through the Caller Display List until you find the telephone number you wish to delete

Press **'MORE'**

Use  and  to scroll through the menu to select **'DELETE'**

Press **'SELECT'** to confirm, a beep will be heard and the next number in the list will be displayed. Or press **'BACK'** to cancel and exit



CALLER DISPLAY

Delete All Entries from the Caller Display List

Press **'MENU'** soft key to activate the menu

Press **'SELECT'** soft key to choose **'CID BOOK'**

Press **'MORE'**

Use  and  to scroll through the menu to select **'DELETE ALL'**

Press **'SELECT'**

'REPEAT' will be displayed



Either press **'SELECT'** soft key to delete all entries or press **'BACK'** to cancel and exit

CALLER DISPLAY



Add Entry from the Caller Display List to Phonebook

Press **'MENU'** soft key to activate the menu

Press **'SELECT'** soft key to choose **'CID BOOK'**

Use  and  to scroll through the Caller Display List until you find the telephone number you wish to add to the phonebook

Press **'MORE'**

Use  and  to scroll through the menu to select **'ADD TO PB'**

Press **'SELECT'**. You will be prompted to enter the name



Enter the name using the alphanumerical keypad (see Phonebook Chapter for explanation)

CALLER DISPLAY

Press '**SAVE**'

Modify the telephone number if required

Press '**SAVE**'

Use  and  to scroll through the menu to select from '**MELODY 1**' to '**MELODY 10**' to select a ring you can associate with this number

Press '**SELECT**' to confirm and exit. A beep will be heard

PHONE BOOK

Telephone numbers can be stored in the phone book. This is very useful for frequently used numbers as you can make a call easily without having to remember or enter the telephone number.

The phone book can contain 50 entries. Each phone number can contain up to 20 digits.

Character Map

Key	Characters
0	(spc) 0 ? / . , !
1	1 @ _ + - " () %
2	A B C a b c 2
3	D E F d e f 3
4	G H I g h i 4
5	J K L j k l 5
6	M N O m n o 6
7	P Q R S p q r s 7
8	T U V t u v 8
9	W X Y Z w x y z 9

Press each key the relevant number of times to get the letter you need e.g. to get the letter J, press the 5 key once, to get the letter S, press the 7 key four times in quick succession.

PHONE BOOK

To move on to the next letter, wait a few seconds and the flashing cursor will appear after the last letter you entered. You may now enter the next letter.

Create a Phone Book Entry

Press **'MENU'** soft key to activate the menu

Press  to select **'PHONEBOOK'**

Press **'SELECT'** soft key

The display will show **'EMPTY'** or the list of numbers already stored.

Press **'SELECT'** soft key and then
Press **'SELECT'** soft key again to select
'NEW'



'NAME ?' will be displayed on the LCD. Enter the name using the alphanumeric keypad (see character map for further explanation)

Press **'SAVE'** soft key

PHONE BOOK

'**NUMBER?**' will be displayed on the LCD. Enter the number (up to 24 digits) using the alphanumeric keypad

Press '**SAVE**' soft key

*Use  and  to scroll through the menu to select from '**MELODY 1**' to '**MELODY 10**' to select a ring you can associate with this number

Press '**SELECT**' soft key to confirm and exit. A confirmation beep will be heard

Note: Use '**ERASE**' soft key to correct a mistake.

'**ERASE**' will clear the last digit entered.


*If you want to set a VIP number, you should select a special ring tone for it. The ring tone should be different from the external ring you have set. You can set up to 9 VIP ring tones that are associated with 9 VIP numbers/groups.

VIP ring tones associate with 9 VIP numbers/groups.


Insert Pause



Inserting a pause provides a delay of 3 seconds. This is necessary with some telephone systems.

PHONE BOOK

To insert a dialling pause between numbers when storing a number, press  until **P** appears in the LCD display.



View Phone Book Entries



In standby mode, press  to access the Phonebook

Use  and  to scroll through the Phonebook until the desired name is displayed

Dialling using a Phone Book Entry

In standby mode, press  to access the Phonebook

Use  and  to scroll through the Phonebook until the desired name is displayed

Press ,  or **'DIAL'** soft key



PHONE BOOK

Modify a Phone Book Entry



Press **'MENU'** soft key to activate the menu

Press  to select **'PHONEBOOK'**

Press **'SELECT'** soft key

Use  and  to scroll through the phonebook until you reach the entry you wish to edit

Press **'SELECT'** soft key



Use  and  to scroll through the menu to select **'EDIT'**.

Press **'SELECT'** soft key

Use **'ERASE'** soft key to delete incorrect characters/digits. Enter the correct name and telephone number

PHONE BOOK


Press **'SAVE'** soft key

Use  and  to scroll through the menu to select from **'MELODY 1'** to **'MELODY 10'** to select a ring you can associate with this number



Press **'SELECT'** soft key to confirm and exit. .
A confirmation beep will be heard

Delete a Phone Book Entry

Press **'MENU'** soft key to activate the menu



Press  to select **'PHONEBOOK'**

Press **'SELECT'** soft key

Use  and  to scroll through the phonebook until you reach the entry you wish to edit

Press **'SELECT'** soft key

PHONE BOOK

Use  and  to scroll through the menu to select **'DELETE'** .



Delete all Phone Book Entries

Press **'MENU'** soft key to activate the menu

Press  to select **'PHONEBOOK'**

Press **'SELECT'** soft key

Press **'SELECT'** soft key

Use  and  to scroll through the menu to select **'DELETE ALL'** .

Press **'SELECT'** soft key

'CONFIRM ?' is displayed


Press **'SELECT'** to confirm or **'BACK'** soft key

PHONE BOOK

to cancel



Phone book Status

Press **'MENU'** soft key to activate the menu

Press  to select **'PHONEBOOK'**

Press **'SELECT'** soft key

Press **'SELECT'** soft key

Use  and  to scroll through the menu to select
'PB STATUS'

The display will show the current phonebook status
e.g.

' 07/50 USED'

This means the phonebook can contain up to 50 entries but 7 of these have been used already

ONE-TOUCH MEMORIES



Storing Memory Numbers

You can store up to 4 numbers in direct memories. All of these numbers will be stored in the phonebook.

Press a memory key (**M1-M4**) in standby mode


'NUMBER?' will be displayed on the LCD.
Enter the number (up to 24 digits) using the alphanumeric keypad

Press **'SAVE'** soft key

Use  and  to scroll through the menu to select from **'MELODY 1'** to **'MELODY 10'** to select a ring you can associate with this number

Press **'SELECT'** soft key to confirm

Viewing Memory Numbers

In standby mode, press  to access the Phonebook

ONE-TOUCH MEMORIES

Use  and  to scroll through the Phonebook until the desired name is displayed


Dialing a Memory Number

Whilst in standby mode, press one of the memory keys (**M1-M4**) to dial out the corresponding number.



Editing a Memory Number

The memory default names are **M1**, **M2**, **M3**, **M4**. You can add a name after them but not delete the default name e.g. **M1** can become **M1:Home**



Press '**MENU**' soft key to activate the menu

Press  to select '**PHONEBOOK**'

Press '**SELECT**' soft key

Use  and  to scroll through the phonebook until you reach the entry you wish to edit

Press '**SELECT**' soft key

Use  and  to scroll through the menu to



ONE-TOUCH MEMORIES

select **'EDIT'** .

Press **'SELECT'** soft key

Use **'ERASE'** soft key to delete incorrect characters/digits. Enter the correct name and telephone number

Press **'SAVE'** soft key

Use  and  to scroll through the menu to select from **'MELODY 1'** to **'MELODY 10'** to select a ring you can associate with this number

Press **'SELECT'** soft key to confirm and exit.

Deleting a Memory Number



The memory default names are **M1, M2, M3, M4..**

Press **'MENU'** soft key to activate the menu

Press  to select **'PHONEBOOK'**

ONE-TOUCH MEMORIES

Press '**SELECT**' soft key

Use  and  to scroll through the phonebook until you reach the entry you wish to edit

Press '**SELECT**' soft key

Use  and  to scroll through the menu to select
'DELETE'.

ADDITIONAL HANDSETS & BASES

The handset that came with your base is already registered to the base (factory setting). This is registered as handset 1. Each additional handset you purchase must be registered to the base.


Up to 5 handsets can be registered to one base unit. This means you can make internal calls between registered handsets, transfer an incoming call between handsets and answer a call anywhere in the office or home at any time as all the handsets will call at the same time.

You can also register up to 4 base units to each handset. This will increase the phone range, allowing you to move between the telephone coverage areas.



, allowing you to move between the telephone coverage areas.

ADDITIONAL HANDSETS & BASES



Register a new Handset

Press and hold  on the base for more than 5 seconds until a prompt tone is heard

Press '**MENU**' soft key to activate the menu

Use  and  to scroll through the menu to select '**REGISTRATION**'

Press **OK**

Use  and  to scroll through the base names list. Select the base number you require

Press '**SELECT**' soft key

The handset will search for the requested base

If the base is found a tone is heard and a number will be assigned and displayed on the LCD.

If the base is not found, a warning tone is heard and the handset returns to the pre-registration state

ADDITIONAL HANDSETS & BASES

Select a Base

Your handset can be used with up to 4 bases.

Note: In order to use the handset with more than one base unit, the handset must be registered with each base (see Register a New Handset section).



Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select
'HS SETTINGS'

Press **'SELECT'** soft key

Use  and  to select
'SELECTED BS'

Press **'SELECT'** soft key

Use  and  to scroll through the base names list. Select the base number you require

Press **'SELECT'** soft key


ADDITIONAL HANDSETS & BASES

The display will first show '**SEARCHING**'
then '**BS SELECTED**'

Internal Calls

When using several handsets registered to the same base unit, you can make internal calls and transfer external calls between handsets.

Make an Internal Call

Press 

Enter the handset number you wish to page (1-5)

Notes:


If an incorrect handset number is entered i.e. one that does not exist, the handset will return to standby

To cancel an internal call, press .



Receive an Internal Call

The paged handset will ring. The calling handset number will be displayed on the LCD display

ADDITIONAL HANDSETS & BASES




Notes:

If there is an external call during the course of an internal call, low beeps will be heard in the background. The internal call can be finished by pressing . The normal external call ring tone will be heard, press  to answer the call.

Call Transfer between Handsets

An external call can be transferred from one handset to another.



ADDITIONAL HANDSETS & BASES

To answer the paged handset, press



If required, you may now speak to the paged user.

To transfer the external call to the paged handset,

press



O | **R**

To cancel the call transfer and talk to the external caller again, press



Notes:

On transferring a call, you may hang up before the paged handset answers. The connection between the external caller and the paged handset is complete once you hang up.

If the paged handset does not answer a call within a predetermined time, the call will be transferred back to your handset.

ADDITIONAL HANDSETS & BASES

Three-way Conference Call


When you have both an external call and an intercom call in progress – you can set up a 3-way call


During an external call, press .

Enter the handset number you wish to transfer to (1-5)

The paged handset will ring. The calling handset number will be displayed on the LCD display

To answer the paged handset, press .

The caller can now press  to invoke a 3-way call

Either of the internal handsets can press  to leave the conference call at any time

CALL WAITING

Caller Display on Call Waiting

When you subscribe to a Call Waiting service from your telephone network, the telephone will display the name and number of the second caller whilst you are having your initial conversation.

Press '**FLASH**' soft key to answer the second caller. The display will show '**R**' .

When you have finished speaking to the second caller, press '**FLASH**' soft key to continue your conversation with the first caller.



Note: The '**FLASH**' soft key sends the flash signal. This key is used in conjunction with special services such as call waiting as mentioned above. For more information about other special services, contact your telephone network provider.

DEFAULT SETTINGS

Handset Reset

You can reset the handset settings to the factory default.

Press **'MENU'** soft key to activate the menu

Use  and  to scroll through the menu to select **'DEFAULT'**

Press **'SELECT'** soft key

You will be prompted to enter the PIN code.

Enter the PIN code (default is 0000).

Press **'SELECT'** soft key


If the PIN is correct, **'CONFIRM'** will be displayed. If the PIN is incorrect, the phone will return to the previous menu

Press **'SELECT'** soft key to confirm, all handset settings will be reset to the factory default and you will be returned to standby. Alternatively, press **'BACK'** to cancel and exit

ACCESSORIES

Optional Accessories

The headset jack is located on the left side of the handset. This jack can accommodate many hands-free headsets. This jack is amplified and you can adjust both tone and volume. It is a standard 2.5mm plug. Simply plug the headset into the jack. The headset will be



TROUBLESHOOTING

General Checks

- Make sure that the telephone line cord and adaptor are correctly plugged in and they are not damaged.
- Make sure the batteries are inserted correctly.
- Make sure that the batteries are fully charged.
- Connect another telephone to the telephone PTT socket or move your telephone to another socket to track if the failure is coming from your telephone or your PTT socket.
- Make sure the power adaptor is properly connected

Handset not registering

- See general checks.

No display

- See general checks
- Check the handset is switched on

No connection between handset and base

- You may be out of range of the base. Move closer to the base

Handset on the base does not charge

- Make sure the handset is placed properly on the base. When charging, the battery symbol should be shown filling up.

Handset does not ring

- See general checks

No tone when you press



- See general checks.

TROUBLESHOOTING

- Check for the handset number on the LCD display e.g. HS1. If this is not present you must register the handset (see Handset Registration section)

A warning tone is heard during a call:

- The batteries are empty. The handset needs to be replaced in the base in order to recharge.
- You are out of the base coverage area.

No number is displayed when the telephone rings:

- Please contact your telephone network provider to get the caller display service.
- Even if you have subscribed to a caller display service, the caller may have withheld their number (private number)
- It could be a call from a PBX. Caller display may not work properly if the telephone is connected to a PBX.

Consistently short battery life

- Clean the charge contacts
- Replace the batteries

Nothing happens when you press any button

- Check the the keylock is switched off

SAFETY INFORMATION

General

Only use the power supply included with the product. Only use the approved rechargeable batteries supplied. Do not open the handset (except to replace the handset batteries) or base. Contact the helpline for all repairs. Never dispose of batteries in a fire. There is a serious risk of explosion and/ or the release of toxic chemicals.

Cleaning

Clean the telephone with a soft cloth. Keep the base and handset charging contacts clean. Never use polishes or cleaning agents - they could damage the finish or the electrics inside.

Environmental

Do not expose to direct sunlight. Always ensure there is a free flow of air over the surfaces of the telephone. Do not place any part of your product in water and do not use it in damp or humid conditions e.g. bathrooms. Do not expose your product to fire or other hazardous conditions. Unplug your phone from the telephone socket during thunderstorms because it could damage your telephone. Your guarantee does not cover thunderstorm damage. The telephone is designed for working within a temperature range of 5°C to 45°C.

GUARANTEE

From the moment your Geemarc product is purchased, Geemarc guarantee it for the period of one year. During this time, all repairs or replacements (at our discretion) are free of charge. Should you experience a problem then contact our help line or visit our website at www.geemarc.com. The guarantee does not cover accidents, negligence or breakages to any parts. The product must not be tampered with or taken apart by anyone who is not an authorized Geemarc representative. The Geemarc guarantee in no way limits your legal rights.

IMPORTANT: YOUR RECEIPT IS PART OF YOUR GUARANTEE AND MUST BE RETAINED AND PRODUCED IN THE EVENT OF AWARRANTY CLAIM.

Please note: The guarantee applies to the United Kingdom only

DECLARATION: Geemarc Telecom SA hereby declares that this product is in compliance with the essential requirements and other relevant provisions of the Radio and Telecommunications Terminal Equipment Directive 1999/5/EEC and in particular article 3 section 1a, 1b and section 3. The telephone does not operate if the line current is lower than 18 mA.

The declaration of conformity may be consulted at www.geemarc.com



GUARANTEE

Electrical connection: The apparatus is designed to operate from a 230V 50Hz supply only. (Classified as 'hazardous voltage' according to EN60950 standard). The apparatus does not incorporate an integral power on/off switch. To disconnect the power, either switch off supply at the mains power socket or unplug the AC adaptor. When installing the apparatus, ensure that the mains power socket is readily accessible.

Telephone connection: Voltages present on the telecommunication network are classified TNV-3 (Telecommunication Network Voltage) according to the EN60950 standard.

RECYCLING DIRECTIVES

The WEEE (Waste Electrical and Electronic Equipment) has been put in place for the products at the end of their useful life are recycled in the best way.

When this product is finished with, please do not put it in your domestic waste bin.

Please use one of the following disposal options:

- Remove the batteries and deposit them in an appropriate WEEE skip. Deposit the product in an appropriate WEEE skip.

- Or, hand the old product to the retailer. If you purchase a new one, they should accept it.

Thus if you respect these instructions you ensure human health and environmental protection.



For product support and help visit our website at

www.geemarc.com

Telephone 01707 384438

Or fax 01707 372529



AmpliDECT400BT_En_v1.0

geemarc UNITED KINGDOM

5 Swallow Court
Swallowfields
Welwyn Garden City
Hertfordshire, AL7 1SB
For product support.
01707 384438

www.geemarc.com

geemarc FRANCE

Parc de l'Etoile
2, rue Galilée BP20061
59791 GRANDE SYNTHÉ CEDEX
TEL. SERVICE APRES VENTE.
03 28 58 75 99

www.geemarc.com